



MACO Homee Wi-Fi Reset

Ensure homee is connected to a power supply


First, ensure that your homee is connected to a power supply.

Press the reset button until the LED flashes orange

Press the reset button on the back of your Brain cube. Hold the button for about 5 seconds, until the LED on the rear of the Brain cube begins to flash orange.



LED
flashes



The reset is successful when the LED turns orange

When the LED on the back of the Brain Cube stops flashing and stays orange, the reset was successful.

Reconnect your homee to your new Wi-Fi network following the guidance within the homee set-up instructions.

LED
lights up
constantly

