



TECHNOLOGY IN MOTION

INSTINCT by MACO

SYSTEM FOLDER – REHAU SYNEGO

instinct^o
by MACO



maco.eu/instinct

Table of contents

Important Information	3
Profile details and matching components	4
Basic design and tolerances	5
Recommended positioning	6 - 7
Milling images	8 - 12
Basic adjustment of the striker plate	13
Cable transitions	14 - 15
Cabling overview	16 - 17
Emergency Release positions	18 - 19
Emergency Release drill pattern	20

Important Information

For the assembly and installation of the INSTINCT by MACO system, you need the following documents:

- › Operating and maintenance instruction
- › System folder for the corresponding door profile
- › Assembly instructions

Operating and maintenance instruction

The operating and maintenance instruction contain important information on project planning, installation, commissioning, operation and maintenance of the INSTINCT by MACO system. This document must be handed over to the client/end user in the course of delivery.

System folder

The system folder contains profile-specific information on the milling and drilling patterns as well as information and notes on cable installation in the profile. In addition, please also note the fabrication guidelines of the profile manufacturer!

Assembly instructions

The assembly instructions contain profile-independent information for the correct assembly of the INSTINCT by MACO system. These instructions include the work steps in the factory and the work steps on the construction site.

Profile details and matching components

PROFILE SYSTEM

Installation of the closures:	In the sash profile
Opening direction:	Inwards opening
Tested sash profile:	REHAU Art. Nr. 1537315
Tested frame profile:	REHAU Art. Nr. 1537015

MATCHING COMPONENTS

Matching closures:	Housing shape A - Art. No. 501_1_
Matching closure covers:	Art. No. 50211_
Recommended screw type(s):	4x DIN 7982 CT / 4.2 x 38
Matching striker plates:	PVC - 13 mm offset - Art. No. 50311_
Matching striker plate covers:	Art. No. 504114
Recommended screw type(s):	4x DIN 7982 CT / 4.2 x 38
Recommended cover profile (profile manufacturer):	REHAU Art. No. 550190

MINIMUM SASH WIDTH

Offset hinges:	≥ 850 mm
Butt hinges:	≥ 850 mm

Basic design and tolerances

Basic setting of the locking cam:	8.5 mm
Basic design of the rebate gap:	12 mm
Minimum rebate gap:	≥ 10 mm
Maximum rebate gap:	≤ 14 mm

IMPORTANT:

Compatibility assessment applies to door hinges with usual rotation curves.
If the rotation curve deviates, the basic setting of the locking cam may have to be adjusted!

Reduction of the minimum rebate gap (by screwing in the locking cam) is:

- Possible Not possible

ATTENTION!

By screwing in the locking cam, the maximum rebate gap is reduced!

Increase of the maximum rebate gap (by screwing out the locking cam) is:

- Possible Not possible

ATTENTION!

By screwing out the locking cam, the minimum rebate gap increases!

DESIGN
& TOLERANCES

MINIMUM
REBATE GAP

MAXIMUM
REBATE GAP

Recommended positioning

DIN L

RECOMMENDED CONFIGURATION

In the minimum configuration, 3 closures are recommended, from a door height of 2500 mm 4 closures are recommended.

An additional horizontal closure is optional.

EXAMPLE DISTANCES*

Door height	Qty	L1	L2
2000	3	240	760
2100	3	240	810
2200	3	240	860
2300	3	240	910
2400	3	240	960
2500	4	240	673
2600	4	240	706
2700	4	240	740
2800	4	240	773


*Figures in mm.
Table valid for DIN L and DIN R.
The values in this table are examples and serve as orientation for the installation of the INSTINCT closures.

Calculation L2 with 3 Closures:

$$\frac{\text{Door height} - (2 \times L1)}{2}$$


Calculation L2 with 4 Closures:

$$\frac{\text{Door height} - (2 \times L1)}{3}$$



Recommended positioning

DIN R



RECOMMENDED CABLE LENGTHS*

L2	Cable length	Item number
$L2 \leq 400$	600	509006
$L2 \leq 500$	700	509007
$L2 \leq 600$	800	509008
$L2 \leq 700$	900	509009
$L2 \leq 800$	1000	509010
$L2 > 800$	1100	509011

*Figures in mm

Depending on the position of the cable routing, the necessary cable lengths may differ.

For the integration of the INSTINCT Bluetooth module or the INSTINCT interface, system cables with a length of 200 (Art. No. 509002), 300 (Art. No. 509003) or 500 mm (Art. No. 509005) are available.


The detailed cabling scheme can be found on Page 16 and 17.

Milling pattern top view

DIN R, M 1:2


NOTE

The hole shown in brown is only required for those closures where cable routing into the glass mounting strip is necessary. For details see Page 16 and 17.



Milling pattern cross-section B-B

DIN R, M 1:1




Milling pattern top view

DIN L, M 1:2


NOTE

The hole shown in brown is only required for those closures where cable routing into the glass mounting strip is necessary. For details see Page 16 and 17.



Milling pattern cross-section C-C

DIN L, M 1:1



Milling pattern cross-section D-D


DIN R, M 1:1

optional milling

INSTINCT Interface 509310


INSTINCT Bluetooth Module 509320

openDoor Touchkey dLine Controller 480489




Basic adjustment of the striker plate

Cross-section A-A, M 1:1






Cable transition

for opening angle $\leq 110^\circ$



Cable transition

for opening angle $\leq 180^\circ$



Cabling overview


For vertical closure points

NOTE

The cable routing is basically carried out in the reinforcement. If cables are to be routed via the sash corners, the cable routing takes place in the glass mounting strip.


For this purpose, an additional hole through the profile is required at the respective cable ends.

For more details see Page 8 - 11.



Cabling overview

For vertical and horizontal closure points



- ① INSTINCT Guard/Guard+
- ② INSTINCT Bluetooth module
- ③ INSTINCT Interface
- ④ MACO OpenDoor Access Control
- ⑤ INSTINCT System cable
- ⑥ INSTINCT cable transition
- ⑦ Termination cable (included with INSTINCT Gateway)

Cable routing

- In the glass holder strip
- In the profile
- In the sash

NOTE

The cable routing basically takes place in the reinforcement. If cables are to be routed via the sash corners, the cable is routed in the glass holder strip. For this purpose, an additional hole through the profile is required at the respective cable ends.

For more details see Page 8 - 11.


Emergency Release positions

DIN L

NOTE


In the event of a defect, it is possible to mechanically open each individual locking point from the inside via an Emergency Release.

For this purpose, the unlocking tool (Art. No. 509520) as well as an Allen key with ball head (4 mm) is required.



Emergency Release positions

DIN R





Emergency Release drill pattern

NOTE

In the event of a defect, it is possible to mechanically open each individual locking point from the inside via an emergency release.


For this purpose, the unlocking tool (Art. No. 509520) as well as an Allen key with ball head (4 mm) is required.



Notes

A large rectangular area filled with a fine grid of light gray lines, intended for writing notes. The grid covers most of the page below the 'Notes' header.

Notes



Notes

A large rectangular area filled with a fine grid pattern, intended for taking notes. The grid consists of small, uniform squares covering the majority of the page's content area.

Mayer & Co Beschläge GmbH

Alpenstraße 173 · 5020 Salzburg · Austria
T: +43 662 6196-0 · F: +43 662 6196-1449
maco@maco.eu · maco.eu

MACO near you:
www.maco.eu/contact



This document is constantly being edited. The current version can be found at <https://www.maco.eu/assets/759593> or scan the QR code.

Created: 05/2022 - changed: 27.01.2023
Order No. 759593
All rights and modifications reserved.

» If I had asked people
what they wanted,
they would have said
faster horses. «

Henry Ford

